

MAKE: SSANGYONG TYPE: Musso

MODEL: YEAR: 1996 on

DETAIL:




SSAN-51

FRONT		TYPE	QTY	PART NUMBER
<p>TORSION BAR Type 'D'</p> <p>Heavy Duty Rate Increased Length 1040mm</p>		D	2	TB53-1800 (Pair)
<p>SHOCK ABSORBER Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		B	2	GS21-463

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Linear Rate Standard Height (10mm Lift)</p> <p>Linear Rate Raised Height (40mm Lift) Medium Load to GVM Recommended</p>			2	C53-003 (Pair)
<p>SHOCK ABSORBER Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		B	2	GS21-637S

MAKE: SSANGYONG **TYPE:** Rexton
 RX270 2.7L TD
MODEL: RX290 2.9L TD **YEAR:** 2002 on
 RX320 3.2L Petrol
DETAIL: Station Wagon



SSAN-52

FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Linear Rate Raised Height (30mm Lift)</p>			2	C53-010 (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>			2	GS53-200

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p> <p>Linear Rate Raised Height (30mm Lift)</p>			2	C53-011 (Pair)
<p>SHOCK ABSORBER</p> <p>Type 'A' 'B' 'C'</p> <p>Heavy Duty Gas</p>		B	2	GS59-223A