

LANDROVER

MAKE: LANDROVER

TYPE: Defender





MODEL: 90 Series



YEAR: 1984 - 1990

DETAIL: SWB



LAND-54

FRONT		QTY	PART NUMBER
COIL SPRING			Price Code (if applicable) ↘
			
Petrol	Linear Rate Raised Height (40mm Lift)	1	C51-014 (B)
	Linear Rate Raised Height (45mm Lift)	1	C51-018 (B)
	50 - 80Kg Accessories (Bull Bar and Winch)	1	C51-018 (B)
Diesel	Linear Rate Raised Height (45mm Lift)	1	C51-018 (B)
	Up to 80Kg Accessories (Bull Bar OR Winch)	1	C51-018 (B)
SHOCK ABSORBER			
			
	Heavy Duty Twin Tube Gas	2	GS51-116
STEERING DAMPER			
			
	Heavy Duty (Big Bore) Complete with Fittings	1	SD51-832
UNDER BODY BUSH KIT			
			
See Rear Under Body Bush Kit			
CASTOR KIT			
Front Radius Arm Castor Kit (±2°)			
4 x Eccentric Polyurethane Bushes			
Pre 1986	Suits 38mm wide leading arm	1	PB51-501K
After 1986	Suits 44mm wide leading arm	1	PB51-502K

REAR		QTY	PART NUMBER
COIL SPRING			Price Code (if applicable) ↘
			
	Linear Rate Raised Height (45mm Lift)	1	C51-015 (B)
	Variable Rate Raised Height (50mm Lift) 220Kg to GVM	1	C51-027V (B)
SHOCK ABSORBER			
			
	Heavy Duty Twin Tube Gas	2	GS51-117
UNDER BODY BUSH KIT			
			
Kit Includes Front & Rear Under Body Bushes			
Chassis Number up to LA930455			
4 x Front Radius Arm to Chassis Bush			
4 x Front Radius Arm to Diff Bush			
2 x Front Panhard Rod Bush			
2 x Rear Upper Arm to Chassis Bush			
2 x Rear Lower Arm to Diff Bush			
4 x Rear Lower Arm to Chassis Bush		1	PB51-1244K
Chassis number LA930456 on			
4 x Front Radius Arm to Chassis Bush			
4 x Front Radius Arm to Diff Bush			
2 x Front Panhard Rod Bush			
2 x Rear Upper Arm to Chassis Bush			
2 x Rear Lower Arm to Diff Bush			
4 x Rear Lower Arm to Chassis Bush		1	PB51-1243K

Raising vehicle will effect castor angle.
A wheel alignment is recommended to determine if a castor kit is required.