

MAKE: LANDROVER **TYPE:** Defender

MODEL: 90 Series **YEAR:** 1984 – 1990

DETAIL: S.W.B.



LAND-54

FRONT		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
Petrol	Linear Rate Raised Height (40mm Lift)		1	C51-014 (Pair)
	Linear Rate Raised Height (45mm Lift) 50-80Kg Accessories		1	C51-018 (Pair)
Diesel	Linear Rate Raised Height (45mm Lift) 80Kg Accessories		1	C51-018 (Pair)
<p>SHOCK ABSORBER</p>				
	Heavy Duty Gas	D	2	GS51-116
<p>STEERING DAMPER Type 'A'</p>				
	Heavy Duty (Big Bore) Complete with Fittings	A	1	SD51-832
<p>UNDER BODY BUSH KIT</p>				
	Polyurethane Bush			
<p>NOTE: See Rear Under Body Bush Kit</p>				
<p>CASTOR KIT</p>				
Front Leading Arm Castor Kit (±2°)				
Kit Contains: 4 x Eccentric Polyurethane Bushes				
Pre 1986 (Suit 38mm wide Leading Arm)		-	1	PB51-501K
Post 1986 (Suit 44mm wide Leading Arm)		-	1	PB51-502K
Raising vehicle will affect castor angle. A wheel alignment is recommended to determine if a castor kit is required.				

REAR		TYPE	QTY	PART NUMBER
<p>COIL SPRING Type 'C'</p>				
	Linear Rate Raised Height (45mm Lift)		1	C51-015 (Pair)
	Variable Rate Raised Height (50mm Lift) 220Kg to GVM		1	C51-027V (Pair)
<p>SHOCK ABSORBER</p>				
	Heavy Duty Gas	C	2	GS51-117
<p>UNDER BODY BUSH KIT</p>				
	Polyurethane Bush			
<p>NOTE: Kit Includes Front & Rear Under Body Bushes</p>				
<p>Chassis Number up to LA930455</p>				
	2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush	-	1	PB51-1244K
<p>Chassis Number LA930456 on</p>				
	2 x Front Panhard Rod Bush 4 x Front Radius Arm to Diff Bush 4 x Front Radius Arm to Chassis Bush 2 x Rear Upper Arm to Chassis Bush 2 x Rear Lower Arm to Diff Bush 4 x Rear Lower Arm to Chassis Bush	-	1	PB51-1243K